



The MIDI THRU BOX is a 1 in 4 out active MIDI thru. It is a simple and effective MIDI distribution system that can be used to power an upstream MIDI device such as a MIDI GO BOX.

### **Default Mode**

Power switch in the OFF position.

In this mode the MIDI THRU BOX functions as a normal 1 in 4 out midi thru.

### **Back Power Mode**

Power switch in the ON position.

This mode sends power back down the midi input line and is intended for use with the MIDI GO BOX. It allows the go box to be used with a single midi cable and removes the need for a separate power supply. We do not recommend using this mode with powered MIDI equipment. This should not cause any physical damage but may cause some systems to malfunction.

